

STAIN SCOOTERS

ASSEMBLY INSTRUCTIONS AND HELPFULL TIPS

1. Take out the scooter from the box and remove all packaging checking you have all components required
2. All nuts and bolts are tightened to factory spec so you **MUST** make sure the headset nut is tight (It's easier before you fit the bar stem!)
3. Slide the handle bar stem on to the forks ensuring the stem has the logo to the front. Notice the fork stem is threaded, so you make have to give the bar stem a wiggle at first to get it to slide on!
4. Now position the handle bar on the stem and screw the stem cap on lightly to stop the bar falling off while you position it correctly. Once you have ensured the bar is central to the stem tighten the Allen key bolts by hand then lock them off tight with the Allen key supplied.
5. Next position the handle bars so they are straight to the front wheel. Once you have it in position screw in the clamp bolts with the Allen key and tighten them off so the bars are secure.
6. Now go over all the bolts again with the Allen key ensuring they are all locked off tight and there is no movement in the stem or bars.

THIS IS VERY IMPORTANT!! IF IT MOVES, IT'S NOT TIGHT!!

BEFORE YOU RIDE:

- Always check the brake works smoothly
- All the bolts are done up tight
- The wheels spin freely and the bar turns smoothly

STAIN